Phone Make/Model	SportDiver SL400-U, SportDiver S SL408	SportDiver Ultra SL405
Samsung Galaxy Note Series	Grip tab size (Left/Bottom)	Grip tab size (Left/Bottom)
Note 20 Ultra 5G	0/S	M/S
Note 20 5G	0/M	M/M
Note 10+ 5G	0/S	M/S
Note 10+	0/S	M/S
Note 10 Lite	0/S	M/M
Note 10	M/M	M/L
Note 9	0/S	M/M
Note 8	0/M	Not supported
Note 4	M/S	Not supported
Note (original)	Does not fit	Not supported
Samsung Galaxy "S" Series	Grip tab size (Left/Bottom)	Grip tab size (Left/Bottom)
S25 Ultra	Does not fit	M/S
S25+	Does not fit	M/M
S25	M/L	M/L
S24 Ultra	Does not fit	M/S
S24+	S/S	M/M
S24 FE	0/S	M/L
S24	Does not fit	M/S
S23 Ultra	Does not fit	M/S
S23+	S/S	M/M
S23 FE	S/S	M/M
S23	M/M	M/L
S22 Ultra	0/S	M/S
S22+	S/M	M/M
S22	M/L	M/L
S21 Ultra 5G	Does not fit	M/M
S21+ 5G	0/M	M/M
S21 5G	M/M	M/L
S21 FE 5G	M/M	M/M
S20 Ultra 5G	Does not fit	M/M
S20+ 5G	0/M	M/M
S20 5G UW	M/L	M/L
S20 FE 5G or 4G	S/M	M/M
S10	M/L	M/L
S10 5G	0/S	M/S
S10+	S/M	M/M
S10E	M/L	M/L
S10 Lite	0/M	M/M
S9	M/L	M/L
S9+	S/M	M/M
S8	M/L	M/L
S8+	S/M	M/M
S7	M/L	Not supported
S7 Edge	M/M	Not supported
S6	M/L	Not supported
S5	M/M	Not supported
S5 mini	M/L	Not supported
S WiFi 4.0	M/L	Not supported
S WiFi 5.0	M/S	Not supported

SIV	M/L	Not supported
SIII	M/L	Not supported
S III mini	Does not fit	Not supported
SII	M/L	• •
S S	M/L	Not supported Not supported
Samsung Galaxy "Z" Series	,	
	Grip tab size (Left/Bottom)	Grip tab size (Left/Bottom)
Z Fold 6 (unfolded)	Does not fit	Does not fit
Z Fold 6 (folded)	Does not fit	Checking fit
Z Fold 5 (unfolded)	Does not fit	Does not fit
Z Fold 5 (folded)	Does not fit	Does not fit
Z Flip 5 (unfolded)	Does not fit	M/L
Z Flip 5 (folded)	Does not fit	Does not fit
Z Fold 4 (unfolded)	Does not fit	Does not fit
Z Fold 4 (folded)	Does not fit	Does not fit
Z Flip 4 (unfolded)	Does not fit	M/L
Z Flip 4 (folded)	Does not fit	Does not fit
Z Fold 3 (unfolded)	Does not fit	Does not fit
Z Fold 3 (folded)	Does not fit	Does not fit
Z Flip 3 (unfolded)	Does not fit	M/L
Z Flip 3 (folded)	Does not fit	Does not fit
Z Fold 2 (Unfolded)	Does not fit	Does not fit
Z Fold 2 (Folded)	Does not fit	Does not fit
Z Flip (Unfolded)	Does not fit	M/M
Z Flip (Folded)	Does not fit	Does not fit
Samsung Galaxy "A" Series	Grip tab size (Left/Bottom)	Grip tab size (Left/Bottom)
A80	Does not fit	M/M
A73 5G	0/S	M/M
A72	Does not fit	M/S
A71	0/S	M/M
A71 5G	0/M	M/M
A71 5G UW	Does not fit	M/M
A70/A70s	0/S	M/M
A55	0/S	M/S
A54 5G	S/S	M/S
A53 5G	S/M	M/M
A52s 5G	Does not fit	M/M
A52 5G	Does not fit	M/M
A51 5G	S/M	M/M
A51	S/M	M/M
A50	S/M	M/M
A41	M/L	M/L
A35	0/S	M/S
A34 5G	0/S	M/S
A33 5G	S/M	M/M
A32 5G	0/S	M/M
A32	S/M	M/M
-	3/101	,
A31	S/M	M/M
		•
A31	S/M	M/M
A31 A30	S/M S/M	M/M M/M
A31 A30 A25	S/M S/M 0/S	M/M M/M M/M
A31 A30 A25 A24 4G	S/M S/M 0/S 0/S	M/M M/M M/M M/S

A21	Does not fit	M/S
A21s	0/M	M/M
A20	S/M	M/M
A16 5G	0/S	M/S
A15	0/S	M/S
A15 5G	0/S	M/S
A14	Does not fit	M/S
A14 5G	Does not fit	M/S
A13 4G (SM-A137)	Does not fit	M/M
A13 5G (SM-A136)	0/S	M/M
A12	Does not fit	M/M
A11	0/S	M/M
A10e	M/L	M/L
A8	M/L	M/L
A8+	Does not fit	M/M
A06	Does not fit	M/S
A05	Does not fit	Does not fit
A04	0/S	M/M
A03	0/S	M/M
A02	0/S	Not supported
A01	M/M	Not supported
Samsung Galaxy "M" Series	Grip tab size (Left/Bottom)	Grip tab size (Left/Bottom)
M53	0/S	M/S
M52 5G	0/S	M/M
M51	0/S	M/M
M31s	S/M	M/M
M31 / M31 Prime Edition	S/M	M/M
M30s	S/M	M/M
M30	S/M	M/M
M21	S/M	M/M
M12	Does not fit	M/M
M11	0/S	M/M
M02 / M02s	Does not fit	M/M
M01 Core	M/L	M/L
Samsung Galaxy "F" Series	Grip tab size (Left/Bottom)	Grip tab size (Left/Bottom)
F62	0/S	M/M
F41	S/M	M/M
F12	Does not fit	M/M
F02s	Does not fit	M/M
Samsung Galaxy "J" Series	Grip tab size (Left/Bottom)	Grip tab size (Left/Bottom)
J5	M/M	M/L
J7	M/S	M/M
Samsung Galaxy "Xcover" Series	Grip tab size (Left/Bottom)	Grip tab size (Left/Bottom)
Xcover Pro	Does not fit	M/M